



## Before you go out and ride, please sign up and register your brand new Denago® EV Nomad XL at

owner.denagoev.com

This step is essential to activate your warranty, receive updates, and join our weekly surprise gift drops inside the Denago® EV Owner Portal. It's a quick step to unlock all the benefits of your purchase.

## Operator Safety

Operators must be well-versed in the controls and functions of the Denago® EV product. Always utilize seat belts and confirm that the vehicle is functioning properly before commencing your drive. To ensure safety, avoid distractions while driving, and keep hands and feet inside the vehicle at all times.

Maintain a safe and controlled speed, particularly in crowded areas. Refrain from making sharp turns or abrupt stops. Operating the vehicle under the influence of alcohol or drugs is strictly prohibited. Regularly check that the vehicle is in good working order before each use.

Be aware of your environment and the current driving conditions. Avoid using the vehicle in extreme weather conditions, such as lightning storms or heavy rain. Exercise caution when driving on slopes or unfamiliar terrains. Before moving, make sure all passengers are seated and securely fastened.

Golf cart and LSV laws and regulations vary from state to state. Please ensure compliance with your local laws before operating.

## **Pre-Operations**

Before operating your Denago® EV product, it's important to conduct a quick visual inspection. Confirm that the vehicle is in the "park position and the parking brake is engaged. Check tire pressure and fluid levels, and verify that there are no loose or broken parts.

To start your Denago® vehicle, insert the key into the ignition switch and turn it to the 'ON' position. On the dashboard, indicators display essential information, including battery status, headlight status, and turn signals.

Ensure that you and all passengers are securely seated with seatbelts fastened. When driving, always keep both hands on the steering wheel and adhere to all traffic regulations.

The brake pedal is positioned on the left, while the accelerator is on the right. To slow down or come to a stop, press the brake pedal. For increasing speed, gently press the accelerator.

Controls for the headlights, tail lights, and horn are conveniently located on the dashboard or steering column. Before each trip, make sure these components are fully functional.

## Now Let's take a closer look at your Denago® EV Nomad XL





















